

63590

SLIDE CABLE INTO SMALL PORTION OF CUTOUT & PLACE PLUG IN BIGGER HOLE

MAX RUN LENGTH PER CIRCIUT 81FT

Continuous Row Instructions:

1. Remove end caps. If ordered with Mate N Loc (MNL) ends will already be removed.
Please remove 2 screws & then pull on end to remove end caps
2. Install beginning of row fixture
3. Slide "Side Joiner Plates" into slots in the mounted fixture.
4. Slide the 2nd fixture in row into "side plate joiner" & butt fixtures together
it is recommended to put the mounting cable in the fixture on the opposite side of where the fixture is going to be joined, swing the fixture into place, and then slide the fixture into the "side plate joiner"
5. Install "U shaped Joiner" by aligning the joiner holes with the holes in the end bracket, and then fasten with the 4 supplied "D" screws.
6. Repeat these steps until row is finished

PARTS LIST		
ITEM	QTY	DESCRIPTION
A	2	FIXTURE
B	1	"U" SHAPED JOINER
C	2	SIDE PLATE JOINER
D	4	SCREW

63590

SLIDE CABLE INTO SMALL PORTION OF CUTOUT & PLACE PLUG IN BIGGER HOLE

MAX RUN LENGTH PER CIRCIUT 81FT

Continuous Row Instructions:

1. Remove end caps. If ordered with Mate N Loc (MNL) ends will already be removed.
Please remove 2 screws & then pull on end to remove end caps
2. Install beginning of row fixture
3. Slide "Side Joiner Plates" into slots in the mounted fixture.
4. Slide the 2nd fixture in row into "side plate joiner" & butt fixtures together
it is recommended to put the mounting cable in the fixture on the opposite side of where the fixture is going to be joined, swing the fixture into place, and then slide the fixture into the "side plate joiner"
5. Install "U shaped Joiner" by aligning the joiner holes with the holes in the end bracket, and then fasten with the 4 supplied "D" screws.
6. Repeat these steps until row is finished

PARTS LIST		
ITEM	QTY	DESCRIPTION
A	2	FIXTURE
B	1	"U" SHAPED JOINER
C	2	SIDE PLATE JOINER
D	4	SCREW

63590

SLIDE CABLE INTO SMALL PORTION OF CUTOUT & PLACE PLUG IN BIGGER HOLE

MAX RUN LENGTH PER CIRCIUT 81FT

Continuous Row Instructions:

1. Remove end caps. If ordered with Mate N Loc (MNL) ends will already be removed.
Please remove 2 screws & then pull on end to remove end caps
2. Install beginning of row fixture
3. Slide "Side Joiner Plates" into slots in the mounted fixture.
4. Slide the 2nd fixture in row into "side plate joiner" & butt fixtures together
it is recommended to put the mounting cable in the fixture on the opposite side of where the fixture is going to be joined, swing the fixture into place, and then slide the fixture into the "side plate joiner"
5. Install "U shaped Joiner" by aligning the joiner holes with the holes in the end bracket, and then fasten with the 4 supplied "D" screws.
6. Repeat these steps until row is finished

PARTS LIST		
ITEM	QTY	DESCRIPTION
A	2	FIXTURE
B	1	"U" SHAPED JOINER
C	2	SIDE PLATE JOINER
D	4	SCREW

63590

SLIDE CABLE INTO SMALL PORTION OF CUTOUT & PLACE PLUG IN BIGGER HOLE

MAX RUN LENGTH PER CIRCIUT 81FT

Continuous Row Instructions:

1. Remove end caps. If ordered with Mate N Loc (MNL) ends will already be removed.
Please remove 2 screws & then pull on end to remove end caps
2. Install beginning of row fixture
3. Slide "Side Joiner Plates" into slots in the mounted fixture.
4. Slide the 2nd fixture in row into "side plate joiner" & butt fixtures together
it is recommended to put the mounting cable in the fixture on the opposite side of where the fixture is going to be joined, swing the fixture into place, and then slide the fixture into the "side plate joiner"
5. Install "U shaped Joiner" by aligning the joiner holes with the holes in the end bracket, and then fasten with the 4 supplied "D" screws.
6. Repeat these steps until row is finished

PARTS LIST		
ITEM	QTY	DESCRIPTION
A	2	FIXTURE
B	1	"U" SHAPED JOINER
C	2	SIDE PLATE JOINER
D	4	SCREW